

## 11.0 GATE LINER INSTALLATION

To install gate liner, follow this procedure:

1. Mount wear plate to gate:
  - a. Bring gate, liner and fasteners to assembly area.
  - b. Align mounting holes at anchor lip end.
  - c. Install anchor bolts and tighten to their specified torque.
  - d. Align next row of bolt holes and tighten fasteners to their specified torque.
  - e. Install and tighten fasteners to their specified torque.



**Gate/Liner**



**Aligning**



**Second Row**



**Installed**

**FIG 11-1 ATTACH WEAR PLATE**

# **DYNAMIC DITCHERS INC.**

**P.O. Box 299  
Dugald, Manitoba  
Canada R0E 0K0**

**Phone: 204-853-2075**

**Fax: 204-853-2076**